

900 NXX Codes

To set up 900 NXX codes for “2-stage” SS7 (applies to GCI ANC 5ESS only)

```
digit transl assign
  1900622-sac (real n=0222) (set real number to carrier)
  1900622-rout list (56)

rout list (56)
  1st choice (56)

rout assignment (56)
  trunk group type (equal access)
  signaling plan number (null)
  sac call (yes)
  ccs7 circuit code (8)
  direct carrier connect (no)
  ccs7 iam number (3)

ccs7 iam assignment (3)
  send transit network selection (yes)
  send carrier id code (yes)
```

To set up 900 NXX codes for “1-stage” SS7 (applies to GCI DEX and AT&T 4ESS)

```
digit transl assign
  1900-rout list (56) or 1900622-rout list (36)

rout list (56)
  1st choice (56)

rout assignment (56)
  trunk group type (direct dialed)
  signaling plan number (null)
  sac call (no)
  ccs7 circuit code (8)
  direct carrier connect (no)
  ccs7 iam number (2)

ccs7 iam assignment (2)
  send transit network selection (no)
  send carrier id code (no)
```

Note: Use AT&T as default route for 900 numbers.